



Brawlerfab.com

sales@brawlerfab.com

A-Pillar Light Mounts

- 1- To install your BrawlerFab A-Pillar Light Mounts, simply work one side at a time and remove the hood mounting nuts, position the BrawlerFab A-Pillar mount over the studs and reinstall nuts. Try to position the hood back in the same spot it was by following the outline of the painted portion of the hood and unpainted (found under the hood hinge assembly). This step will be easier with an extra set of hands. Tighten the nuts and move to the other side and repeat.
- 2- Mount your lights to the BrawlerFab A-Pillar Mount using the hardware that came with your lights.
- 3- Route the wires so that they do not get pinched with closing the hood or cause interference with the windshield wipers.
- 4- Wire your lights to any one of your AUX switches. Harness can be found in front of the battery on the drivers side.
- 5- Once you have routed the wires, close the hood and adjust the lights to the placement you prefer. Due to differences in manufacturing these mounts as well as slight differences between each truck, you may need to tweak the mounts to get the lights level. Simply push up on the light mount to achieve a level mount.

Congratulations! You have completed the installation of your BrawlerFab A-Pillar Light Mount!